

FÄRG

FÄRG is made with the intention of being easy to use by everyone, this means that you can do it yourself. Follow this guide closely for the best result. If you have any further questions regarding application please contact your retailer.

GUIDE

NB: Stops during the application will give an uneven color rendition on the finished FÄRG wall, so be sure to spackle the entire wall without stops.

1

Cover everything around the wall(s) that you wish to spackle. Use masking tape for the edges, and plastic or paper for protecting your floors. Make sure your walls are clean and dry.

2

Apply the first layer of compound with a regular wide scraper (we recommend size 15 cm or 35 cm). If you apply with small strokes and many overlaps, the result will be wilder and livelier whereas, if you on the other hand use long strokes and few overlaps, your result will be calmer.

Remove the masking tape after the first layer, before the wall dries. Let the wall dry for at least 16 hours, before you continue with the second and last layer.

3

Sand runners and edges with sandpaper on a block and dust of the wall afterwards. Reapply masking tape and apply the second layer of compound. The layers should be even throughout the wall, but no thicker than 4 mm.

Remove the masking tape after applying the second layer. Let it dry for minimum 16 hours or until it feels dry.

4

Sand the entire surface of the wall, with sandpaper grit 120 or 180. It is important to sand by hand in soft circular strokes, until the wall doesn't have any visible craters or edges. Dust of the wall and keep the floor covered for the last treatment; the sealer.

5

Apply one layer of the sealer, with a paint roller. Avoid runners, they will be very visible and not very pretty. Did you buy the sealer as a spray, then apply in two turns with the atomizer. Dry any runners that might appear.

Remove all tape and covers while the sealer is still wet. Finally let it dry for 24 hours before usage - afterwards your wall is finished. Good job!